

# **GMK CARE CATALOGUE**

GMK MAINTENANCE PARTS, TOOLS & 04/2025



# EXTEND THE LIFE OF YOUR CRANE

Dear Customer,

Thank you for trusting our cranes for your rigging and lifting solutions. We look forward to serving you and servicing your cranes throughout their lifespan. Our global network of service locations and dealers is ready to provide expert support for your technical and operational questions.

Since 1902, The Manitowoc Company, Inc., a global crane manufacturer and lifting solution provider, has been serving customers like you, as we Build Something Real in the world, through our product brands of Grove, Manitowoc, National Crane Potain, and Shuttlelift. It is our mission to keep your cranes in optimal condition and performance to maximize the return on your investment.

This Care catalog provides a quick reference for common maintenance items, tools, and repair options. For all your parts and service inquiries and lifting solution needs, please reach out to one of our service locations or dealers.

To download the latest version of this brochure please scan the QR code.



https://www.manitowoc.com/parts/mobile-cranes-parts



# CONTENTS

Maintenance Kits	4	
500 Hours Maintenance Kits	6	
1000 Hours Maintenance Kits	9	
2000 Hours Maintenance Kits	14	
Lubrication	18	
Boom Grease Spay Set	22	
Boom Lubrication Kit	23	
Spray Lance Set	24	
Rope Cleaner	26	
Accumulator Charging Kit	30	
Boom Head Camerasystem	32	
Other Useful Kits and Tools	34	
Training	36	
Diagnostic Tools	38	
Grove CONNECT	40	
Maintenance App	42	
Rebuild - Encore		
Remanufacture	46	
Come Clean	47	
Notes	49	

#### FIND YOUR LOCAL DEALER AT:



**GROVE**®

# MAINTENANCE KITS

Simple to order, cost-effective and easily available:

GMK Maintenance kits help keep your all-terrain crane making money for you.





## NOW WITH USER GUIDES

For all of the maintenance kits, with details of the kit contents, where the filters and seals are used, and additional items that we offer to fulfill the planned maintenance.

You can download these guides from our website under: https://www.manitowoc.com/parts/mobile-cranes-parts



#### PRICING ADVANTAGE

Benefit from substantial savings by buying kits instead of individual parts.

#### **CRANE RELIABILITY**

Regular preventive maintenance ensures good reliability.

#### PLEASE NOTE:

The maintenance kits do not contain any fluids or greases. These are available for ordering separately. Details in the user guides.



# MAINTENANCE KITS



# **500 HOURS**



The best and most convenient time to exchange a faulty or worn seal is during a visual check.

The 500h kit is equivalent to a three–to–six–month inspection.\* The details of certain maintenance steps are described in the maintenance manuals.

Grove CONNECT supports the GMK Maintenance kits with serial number display, notification and acknowledgement.



<sup>\*</sup>The content of the kit may differ between models.

GMK 3050-2         Cummins         T4F/E5         3050 2501         3 302 853/5         04425781           GMK 3050-3         Cummins         T4F/E5         3050 1501         3 303 129/30         04425780           GMK 3060-2         Cummins         T4F/E5         3060 2601         3 303 129/30         04425780           GMK 3060-1         Cummins         T4F/E5         3060 2601         3 303 131/2         04425780           GMK 3060-1         Cummins         T3         3060 1601         3 303 086/7         04425780           GMK 4080-3         Mercedes         E5         4080 4101         3 303 190/1         04425837           GMK 4090-1         Mercedes         E5         4080 4101         3 303 188/9         04425837           GMK 4100L-2         Mercedes         E5         4090 4101         3 303 149/50         04425837           GMK 4070L         Mercedes         E5         4090 4080         3 303 149/50         04425837           GMK 5120L         Mercedes         E5         4070 0001         4 409 058/9         04425832           GMK 5150-1         Mercedes         E5         5150 5501         3 303 262/3         04425745           GMK 5150L-1         Mercedes         T4F         5150 050	Crane Model	Engi	ne	Crane S/No start	Maintenance Manual	500H Kit P/No	
GMK 3050-3         Cummins         T3         3050 1501         04425780           GMK 3060-2         Cummins         T4F / E5         3050 2501         3 303 129/30         04425781           GMK 3060-2         Cummins         T4F / E5         3060 2601         3 303 131/2         04425780           GMK 3060L-1         Cummins         T4F / E5         3060 7101         3 303 086/7         04425780           GMK 4080-3         Mercedes         E5         4080 4101         3 303 190/1         04425837           GMK 4090-1         Mercedes         E5         4080 4101         3 303 188/9         04425837           GMK 4100L-2         Mercedes         E5         4090 4101         3 303 188/9         04425837           GMK 4070L         Mercedes         E5         4090 4101         3 303 149/50         04425837           GMK 4080L         Mercedes         E5         4100 4250         4409 058/9         04425837           GMK 4080L         Mercedes         E5         4070 0001         4409 058/9         04425832           GMK 5120L         Mercedes         T3         5120 5601         3 303 262/3         04425745           GMK 5150-1         Mercedes         T4F         5150 0501         3 302 979/80<	CN41/ 2050 2	C	T4F / E5	3050 2501	2 202 052/5	04425781	
GMK 3050-3         Cummins         T3         3050 1601         3 303 129/30         04425780           GMK 3060-2         Cummins         T4F / E5         3060 2601         3 303 131/2         04425781           GMK 3060L-1         Cummins         T4F / E5         3060 1601         3 303 086/7         04425780           GMK 4080-3         Mercedes         E5         4080 4101         3 303 190/1         04425837           GMK 4090-1         Mercedes         E5         4080 4080         3 303 188/9         04425837           GMK 4100L-2         Mercedes         E5         4090 4101         3 303 188/9         04425837           GMK 4070L         Mercedes         E5         4090 4101         3 303 149/50         04425837           GMK 4070L         Mercedes         E5         4100 4301         3 303 149/50         04425837           GMK 4080L         Mercedes         E5         4070 0001         4 409 058/9         04425837           GMK 5120L         Mercedes         T3         5120 5601         3 303 262/3         04425745           GMK 5150-1         Mercedes         T4F         5150 3501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 5001<	GMK 3050-2	Cummins	Т3	3050 1501	3 302 853/5	04425780	
GMK 3060-2 Cummins	CN41/ 2050 2	C	T4F / E5	3050 2501	2 202 420 /20	04425781	
GMK 3060-2         Cummins         T3         3060 1601         3 303 131/2         04425780           GMK 3060L-1         Cummins         T4F / E5         3060 7101         3 303 086/7         04425781           GMK 4080-3         Mercedes         E5         4080 4101         3 303 190/1         04425837           GMK 4090-1         Mercedes         E5         4080 4080         3 303 188/9         04425837           GMK 4090-1         Mercedes         E5         4090 4101         3 303 188/9         04425837           GMK 4100L-2         Mercedes         E5         4090 4101         3 303 149/50         04425837           GMK 4070L         Mercedes         E5         4090 4101         3 303 149/50         04425837           GMK 4080L         T3         4100 4250         4409 058/9         04425837           GMK 4080L         Mercedes         E5         4070 0001         4409 058/9         04425832           GMK 5120L         Mercedes         E5         5120 5601         3 303 262/3         04425832           GMK 5150-1         Mercedes         T4F         5150 0501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 1501         3 303 259/60	GMK 3050-3	Cummins	Т3	3050 1601	3 303 129/30	04425780	
T3         3060 1601         04425780           GMK 3060L-1         Cummins         T4F / E5         3060 7101         3 303 086/7         04425780           GMK 4080-3         Mercedes         E5         4080 5101         3 303 190/1         04425837           GMK 4090-1         Mercedes         E5         4080 4101         3 303 190/1         04425837           GMK 4090-1         Mercedes         E5         4090 4101         3 303 188/9         04425837           GMK 4100L-2         Mercedes         E5         4090 4101         3 303 149/50         04425837           GMK 4070L         Mercedes         E5         4100 7101         3 303 149/50         04425837           GMK 4070L         Mercedes         E5         4070 0001         4 409 058/9         04425837           GMK 4080L         T3         4070 1001         4 409 058/9         04425832           GMK 5120L         Mercedes         E5         5120 5601         3 303 262/3         04425832           GMK 5150-1         Mercedes         T4F         5150 3501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 4501         3 302 977/8         04414510           GMK 5150XL<	CMK 2000 2	Cumamaina	T4F / E5	3060 2601	2 202 121/2	04425781	
GMK 3060L-1         Cummins         T3         3060 4601         3303 086/7         04425780           GMK 4080-3         Mercedes         E5         4080 5101         3 303 190/1         04425837           GMK 4090-1         Mercedes         E5         4080 4101         3 303 188/9         04425837           GMK 4090-1         Mercedes         E5         4090 4101         3 303 188/9         04425837           GMK 4100L-2         Mercedes         E5         4100 4301         3 303 149/50         04425837           GMK 4070L         Mercedes         E5         4070 0001         4 409 058/9         04425837           GMK 4080L         Mercedes         E5         4070 0001         4 409 058/9         04425832           GMK 5120L         Mercedes         E5         5120 5601         3 303 262/3         04425745           GMK 5150-1         Mercedes         T4F         5150 3501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 4501         3 302 977/8         04414510           GMK 5150L         Mercedes         E5         5150 8001         3 302 935/6         04414510           GMK 5180-1         Mercedes         E5         5180 6001	GMK 3060-2	Cummins	T3	3060 1601	3 303 131/2	04425780	
T3 3060 4601 0442580  T3 4080 5101 3 303 190/1 04425837  T4F 4080 4080  GMK 4090-1 Mercedes E5 4090 4101 3 303 188/9 04425837  T4F 4090 4080  GMK 4100L-2 Mercedes E5 4100 4301 3 303 149/50 04425837  T4F 4100 4250  GMK 4070L  GMK 4070L  GMK 4080L  GMK 5120L  GMK 5120L  GMK 5150-1 Mercedes E5 5150 3501 T4F 5150 0501 3 302 979/80 04414510  GMK 5150L-1 Mercedes E5 5150 8001 T4F 5150 5001 T4F 5180 5001 T4F 518	CMIX 20001 1	Cumamaina	T4F / E5	3060 7101	2 202 000/7	04425781	
GMK 4080-3         Mercedes         E5         4080 4101         3 303 190/1         04425837           GMK 4090-1         Mercedes         E5         4090 4101         3 303 188/9         04425837           GMK 4090-1         Mercedes         E5         4090 4080         3 303 188/9         04425837           GMK 4100L-2         Mercedes         E5         4100 4301         3 303 149/50         04425837           GMK 4070L         T3         4100 7101         3 303 149/50         04425837           GMK 4080L         E5         4070 0001         4 409 058/9         04425837           GMK 5120L         Mercedes         E5         4070 0001         4 409 058/9         04425832           GMK 5150-1         Mercedes         T3         5120 5601         3 303 262/3         04425745           GMK 5150-1         Mercedes         T4F         5150 3501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 0501         3 302 977/8         04414510           GMK 5150L         Mercedes         T3         5150 6001         3 303 259/60         04414510           GMK 5180-1         Mercedes         T3         5150 6001         3 302 935/6         04425829	GMK 3060L-1	Cummins	T3	3060 4601	3 303 086//	04425780	
T4F 4080 4080  GMK 4090-1 Mercedes E5 4090 4101  T4F 4090 4080  T3 4090 5101  T4F 4090 4080  T3 4100 7101  T4F 4100 4250  T4F 4100 4250  E5 4070 0001  T3 4070 1001  E5 4080 0001  T3 4080 1001  T3 4070 1001  T3 4080 1001  T3 5120 5601  E5 5120 5101  T3 5150 5501  T3 5150 5501  T3 5150 7501  T3 5150 4501  T3 5150 9501  T3 5150 9501  T3 5150 9501  T3 5150 8001  T3 5150 8001  T3 5180 5001  T3 5180 5501  T3 5180 5501  T3 5180 5501  T3 5180 5501  T4F 5180 5501  T3 5180 5501  T3 5180 5501  T3 5180 5501  T4F 5180 5501  T3 5180 5501  T3 5180 5501  T4F 5180 5501  T3 5180 5501  T4F 5180 5501			T3	4080 5101			
GMK 4090-1 Mercedes	GMK 4080-3	Mercedes	E5	4080 4101	3 303 190/1	04425837	
GMK 4090-1         Mercedes         E5         4090 4101         3 303 188/9         04425837           T4F         4090 4080         T3         4100 7101         3 303 149/50         04425837           GMK 4100L-2         Mercedes         E5         4100 4301         3 303 149/50         04425837           GMK 4070L         Mercedes         E5         4070 0001         409 058/9         04425832           GMK 4080L         T3         4080 1001         3 303 262/3         04425745           GMK 5120L         Mercedes         E5         5120 5601         3 302 979/80         04414510           GMK 5150-1         Mercedes         T4F         5150 0501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 1501         3 302 977/8         04414510           GMK 5150XL         Mercedes         E5         5150 8001         3 303 259/60         04414510           GMK 5180-1         Mercedes         E5         5180 5001         3 302 935/6         04425829           GMK 5180-1         Mercedes         E5         5180 8501         3 303 080         04425829			T4F	4080 4080			
T4F       4090 4080         GMK 4100L-2       Mercedes       E5       4100 7101       3 303 149/50       04425837         GMK 4070L       Mercedes       E5       4100 4250       4409 058/9       04425832         GMK 4080L       Mercedes       E5       4070 0001       4409 058/9       04425832         GMK 5120L       Mercedes       T3       5120 5601       3 303 262/3       04425745         E5       5150 3501       3 302 979/80       04414510         GMK 5150L-1       Mercedes       T4F       5150 0501       3 302 977/8       04414510         GMK 5150XL       Mercedes       E5       5150 8001       3 303 259/60       04414510         GMK 5180-1       Mercedes       E5       5150 8001       3 302 935/6       04414510         GMK 5180-1       Mercedes       E5       5180 8501       3 303 080       04425829         GMK 5200-1       Mercedes       T4F       5180 5501       3 303 746       04425829			Т3	4090 5101			
GMK 4100L-2         Mercedes         T3         4100 7101         3 303 149/50         04425837           GMK 4070L         T4F         4100 4250         04425837           GMK 4070L         E5         4070 0001         4409 058/9         04425832           GMK 4080L         T3         4080 0001         3 303 262/3         04425832           GMK 5120L         Mercedes         T3         5120 5601         3 303 262/3         04425745           GMK 5150-1         Mercedes         T4F         5150 3501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 0501         3 302 977/8         04414510           GMK 5150L-1         Mercedes         T4F         5150 1501         3 302 977/8         04414510           GMK 5150XL         Mercedes         E5         5150 8001         3 303 259/60         04414510           GMK 5180-1         Mercedes         T4F         5180 5001         3 302 935/6         04425829           GMK 5180-1         Mercedes         T4F         5180 6001         3 303 080         04425829	GMK 4090-1	Mercedes	E5	4090 4101	3 303 188/9	04425837	
GMK 4100L-2         Mercedes         E5         4100 4301         3 303 149/50         04425837           GMK 4070L         Augusta 1001         E5         4070 0001         Augusta 1001         Au			T4F	4090 4080	]		
GMK 4070L  GMK 4080L  GMK 4080L  GMK 5120L  Mercedes  GMK 5150-1  GMK 5150L-1  GMK 5150XL  Mercedes  GMK 5180-1  Mercedes  GMK 5180-1  Mercedes  T4F  4100 4250  E5			Т3	4100 7101			
E5         4070 0001         4 409 058/9         04425832           GMK 4080L         T3         4070 1001         4 409 058/9         04425832           GMK 4080L         T3         4080 1001         3 303 262/3         04425745           GMK 5120L         Mercedes         E5         5120 5101         3 303 262/3         04425745           GMK 5150-1         Mercedes         T4F         5150 0501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 1501         3 302 977/8         04414510           GMK 5150XL         Mercedes         T4F         5150 8001         3 303 259/60         04414510           GMK 5180-1         Mercedes         T3         5150 6001         3 302 935/6         04414510           GMK 5180-1         Mercedes         E5         5180 5001         3 302 935/6         04425829           GMK 5200-1         Mercedes         T4F         5200 5501         3 302 746         04425829	GMK 4100L-2	Mercedes	E5	4100 4301	3 303 149/50	04425837	
GMK 4070L         Mercedes         T3			T4F	4100 4250			
Mercedes         T3 4070 1001 4 409 058/9         04425832           GMK 4080L         E5 4080 0001 T3 4080 1001         4 409 058/9         04425832           GMK 5120L         Mercedes         T3 5120 5601 T3 303 262/3         04425745           GMK 5150-1         Mercedes         T4F 5150 3501 T3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F 5150 4501 T3 302 977/8         04414510           GMK 5150XL         Mercedes         T4F 5150 8001 T3 303 259/60         04414510           GMK 5180-1         Mercedes         T4F 5180 5001 T3 302 935/6         04425829           GMK 5200-1         Mercedes         T4F 5200 5501 T3 302 746         04425829	CMIC 40701		E5	4070 0001			
GMK 4080L         E5         4080 0001           T3         4080 1001           GMK 5120L         Mercedes         T3         5120 5601         3 303 262/3         04425745           GMK 5150-1         Mercedes         T4F         5150 3501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         T4F         5150 4501         3 302 977/8         04414510           GMK 5150L-1         Mercedes         T4F         5150 1501         3 302 977/8         04414510           GMK 5150XL         Mercedes         E5         5150 8001         3 303 259/60         04414510           GMK 5180-1         Mercedes         T4F         5180 5001         3 302 935/6         04425829           GMK 5200-1         Mercedes         T4F         5200 5501         3 302 746         04425829	GMK 4070L	l	T3	4070 1001	4 409 058/9	04425022	
GMK 5120L Mercedes	CMIC 40001	Mercedes	E5	4080 0001		04425652	
GMK 5120L Mercedes E5 5120 5101 3 303 262/3 04425745  E5 5120 5101 3 303 262/3 04425745  E5 5150 3501 3 302 979/80 04414510  T3 5150 7501 3 302 979/80 04414510  E5 5150 4501 3 302 977/8 04414510  T3 5150 9501 3 302 977/8 04414510  T3 5150 8001 3 303 259/60 04414510  GMK 5180-1 Mercedes E5 5180 8501 3 302 935/6  E3A 5180 6001 3 302 935/6  E3A 5180 6001 3 303 289  GMK 5200-1 Mercedes T4F 5200 5501 3 302 746 04425829	GMK 4080L		T3	4080 1001			
GMK 5150-1 Mercedes	CMK E1201	Managalaa	T3	5120 5601	2 202 202/2	04425745	
GMK 5150-1         Mercedes         T4F         5150 0501         3 302 979/80         04414510           GMK 5150L-1         Mercedes         E5         5150 4501         3 302 977/8         04414510           GMK 5150L-1         Mercedes         T4F         5150 1501         3 302 977/8         04414510           GMK 5150XL         Mercedes         E5         5150 8001         3 303 259/60         04414510           T3         5150 6001         3 302 935/6         04414510           GMK 5180-1         Mercedes         E3A         5180 6001         3 302 935/6         04425829           GMK 5200-1         Mercedes         T4F         5200 5501         3 302 746         04425829	GMK 5120L	Mercedes	E5	5120 5101	3 303 202/3	04425745	
T3 5150 7501  E5 5150 4501  T4F 5150 1501 3 302 977/8 04414510  T3 5150 9501  GMK 5150XL Mercedes  T4F 5150 8001  T3 5150 6001  T4F 5180 5001  GMK 5180-1  Mercedes  T4F 5180 6001  T3 5180 6001  T3 5180 6001  T3 5180 6001  T3 5180 5501  T3 5180 5501  T3 5180 5501  T4F 5200 5501			E5	5150 3501			
GMK 5150L-1 Mercedes T4F 5150 4501  GMK 5150L-1 Mercedes T4F 5150 1501  T3 5150 9501  T3 5150 8001  T3 5150 6001  T3 5150 6001  T4F 5180 5001  GMK 5180-1 Mercedes E5 5180 8501  T3 5180 6001  T3 5180 5501  T3 5180 5501  T4F 5200 5501	GMK 5150-1	Mercedes	T4F	5150 0501	3 302 979/80	04414510	
GMK 5150L-1         Mercedes         T4F         5150 1501         3 302 977/8         04414510           GMK 5150XL         Mercedes         E5         5150 8001         3 303 259/60         04414510           GMK 5150XL         Mercedes         T3         5150 6001         3 303 259/60         04414510           GMK 5180-1         Mercedes         E3A         5180 5001         3 302 935/6         04425829           GMK 5200-1         Mercedes         T4F         5200 5501         3 302 746         04425829			T3	5150 7501			
GMK 5150XL Mercedes			E5	5150 4501			
GMK 5150XL Mercedes E5 5150 8001 3 303 259/60 04414510  T3 5150 6001 3 303 259/60 04414510  T4F 5180 5001 3 302 935/6  E3A 5180 6001 3 302 935/6  E5 5180 8501 3 303 080  T3 5180 5501 3 302 746 04425829	GMK 5150L-1	Mercedes	T4F	5150 1501	3 302 977/8	04414510	
GMK 5150XL Mercedes T3 5150 6001 3 303 259/60 04414510  T4F 5180 5001 3 302 935/6  E3A 5180 6001 3 302 935/6  E5 5180 8501 3 303 080  GMK 5200-1 Mercedes T4F 5200 5501 3 302 746 04425829			T3	5150 9501			
GMK 5180-1 Mercedes T3 5150 6001  T4F 5180 5001 E3A 5180 6001  E5 5180 8501 T3 5180 5501  T3 5180 5501  T4F 5200 5501	CMK E1EOVI	Maraadas	E5	5150 8001	3 303 350/00	04414510	
GMK 5180-1 Mercedes E3A 5180 6001 3 302 935/6 04425829   E5 5180 8501 3 303 080   T3 5180 5501 3 302 746 04425829   GMK 5200-1 Mercedes   T4F 5200 5501 3 302 746 04425829	GIVIN STOUXL	iviercedes	T3	5150 6001	3 303 259/60	U4414510	
GMK 5180-1 Mercedes E3A 5180 6001 04425829  E5 5180 8501 3 303 080  T3 5180 5501 3 302 746  GMK 5200-1 Mercedes 04425829			T4F	5180 5001	2 202 025 /0		
E5 5180 8501 3 303 080  T3 5180 5501 3 302 746  GMK 5200-1 Mercedes 74F 5200 5501 3 302 746	CMK E190 1	Marranda	E3A	5180 6001	3 302 935/6	04425829	
T3 5180 5501  GMK 5200-1 Mercedes T4F 5200 5501 3 302 746 04425829	GIVIK 5180-1	wercedes	E5	5180 8501	2 202 000		
GMK 5200-1 Mercedes 04425829			T3	5180 5501	3 303 080		
E5 5200 8501 3 303 081/2 04425829	CMK 5200 4	Maraadas	T4F	5200 5501	3 302 746	04435930	
	GIVIK 5200-1	iviercedes	E5	5200 8501	3 303 081/2	04425829	



Crane Model	Engine		Crane S/No start	Maintenance Manual	500H Kit P/No
GMK 5250L	Marsadas	T4F	5250 5001	3 302 744	04425020
GIMIK 5250L	Mercedes	E3A	5250 6001	3 302 /44	04425829
		T4F	5250 5501	3 302 870/1	
GMK 5250L-1	Mercedes	E5	5250 7001	3 303 050/1	04425829
		Т3	5250 6501	3 303 050/1	
		T4F	5250 8501	3 302 965/6	
GMK 5250XL-1	Mercedes	E5	5250 9501	2 202 077/0	04425829
		T3	5250 4501	3 303 077/8	
GMK 6300L	Mercedes	T4F	6300 5001	3 302 443/4 or	04425934
GIVIK 0300L	Mercedes	Т3	6300 3001	3 302 807	04425927
		T4F	6300 5096		04425934
GMK 6300L-1	Mercedes	E5	6300 6001	3 302 718/9 or 3 302 873/4	04425835
		Т3	6300 3502		04425927
GMK 6400-1	Mercedes	E5	6400 4001	3 303 218	04414169
GIVIN 0400-1   IVIERCEGES	iviercedes	Т3	6400 3501	3 303 218	04414168
GMK 6450-1	Mercedes	E5	6400 4001	3 303 251 or	0.444.44.05
GIVIN 0450-1	iviercedes	Т3	6400 3501	4 409 /15/29/30	04414168

Whatever the circumstance, regular maintenance ensures your crane is in good working order!



# MAINTENANCE KITS



## **1000 HOURS**



Good maintenance at regular intervals will make a difference in the daily reliability and long-term life of your GMK. The 1000h kit is equivalent to a 12-month inspection.\* Grove CONNECT supports the GMK Maintenance kits with serial number display, notification and acknowledgement.



<sup>\*</sup>The content of the kit may differ between models.

Crane Model	Engi	Engine		Maintenance Manual	1000H Kit P/No
GMK 2035E	Mercedes	E3A	2035 2001	3 112 340/1 or 3 112 983/4	03065750
GMK 3050-1	Mercedes	E3A	3050 2001	3 112 547/8 or	03065749
GIWIN 3030-1	Mercedes	E3B	3050 1001	3 112 739/40	03003749
		E3A	3055 9001		
GMK 3055	Mercedes	E3A	3055 2001	3 112 547/8 or 3 112 739/40	03065749
		E3B	3055 1001		
GMK 3060	Mercedes	E3A	3060 4101	3 112 882/3 or	03065749
GIMK 3000	Mercedes	E§B	3060 5001	3 302 476/7	03003749
GMK 3060C	Cummins	T4F* *(some T3 downgra- des)	3060 6001	3 302 573/4	04241475
		T4F/E5	3050 2501	3 302 853/5	04299742
GMK 3050-2	Cummins	T3	3050 1501		04299741
GMK 3050-3	Cummins	T4F/E5	3050 2501	3 303 129/30	04299742
GWIN 3030 3	Cullillillis	T3	3050 1601	3 303 129/30	04299741
CMW 2000 4	0	T4F/E5	3060 2601	2 202 000/4	04299742
GMK 3060-1	Cummins	T3	3060 1501	3 302 990/1	04299741
GMK 3060-2	Cummins	T4F/E5	3060 2601	3 303 131/2	04299742
GMK 3000-2	Cullillins	T3	3060 1601	3 303 131/2	04299741
GMK 3060L	Cummins	T4F/E5	3060 7001	3 302 778/9	04299742
GWIN SOUCE	Cumming	T3	3060 4501	3 302 110/3	04299741
GMK 3060L-1	Cummins	T4F/E5	3060 7101	3 303 086/7	04299742
GMK 3060L-1	Cummins	T3	3060 4601	3 303 086/7	04299741
GMk 4080-1	Mercedes	E3A	4080 2001	3 112 742/3 or	04175660
GIVIK 4000-1	iviercedes	E3B	4080 3001	3 113 167/8 or 3 113 169/70	04173000
GMK 4100	Mercedes	Chassis E3B	4100 6001	3 112 748/9 or	03065742
GMK 4100L	INICICEUES	Super E3A	4100 0001	3 112 628/9	03003742
GMK 4100	Mercedes	Chassis E3B	4100 6501	3 113 094/5 or	04361946
GMK 4100L	Mercedes	Super E3B	4100 0501	3 113 101/2	04301340



Crane Model	Engine		Crane S/No start	Maintenance Manual	1000H Kit P/No
GMK 4080-2	Mercedes	T4F	4080 4001	3 302 759/60	0.4101202
GMK 4080-2	Merceues	T3	4080 5001	3 302 759/60	04181392
0141/ 4000		T4F	4090 4003	0.000.040/0	0.4101000
GMK 4090	Mercedes	T3	4090 5001	3 302 648/9	04181392
		T4F	4100 7001		0.4404000
GMK 4100L-1	Mercedes	T3	4100 4001	3 302 363/4	04181392
		T3	4080 5101		0.4004.000
GMK 4080-3	Mercedes	E5	4080 4101	3 303 190/1	04361962
		T4F	4080 4080		04361969
		T3	4090 5101		04361962
GMK 4090-1	Mercedes	E5	4090 4101	3 303 188/9	04301302
		T4F	4090 4080		04361969
		T3	4100 7101		04361962
GMK 4100L-2	Mercedes	E5	4100 4301	3 303 149/50	
		T4F	4100 4250		04361969
GMK 4070L		E5	4070 0001		04425833
GMK 40/0L	Mercedes	T3	4070 1001	4 409 058/9	
GMK 4080L	Mercedes	E5	4080 0001	4 409 030/9	
GIMK 4080L		T3	4080 1001		
GMK 5095	Mercedes	Chassis E3B		3 112 873/4	03144113
GMK 5095	Mercedes	Super E3A	5095 5004	3 112 07 3/4	03144113
0141/5005		Chassis E3B	5005 5504	0.110.007/0	0.40040.47
GMK 5095	Mercedes	Super E3B	5095 5501	3 113 097/8	04361947
0.005.00		Chassis E3B	5.1.0.000.	0.110.01140	00111015
GMK 5110-1 Merce	Mercedes	Super E3A	5110 6001	3 112 811/2	03144315
GMK 5130- 2	MV5120 2 Mare 1	Chassis E3B	5130 7001	3 112 751/2	03144315
GMK 5130-2 Merced		Super E3A	5130 /001	3112/31/2	U31 <del>44</del> 313
GMK 5110-1	Mercedes	Chassis E3B	5110 6501	3 113 099/100	04182405
GIMIN 3110-1	Mercedes	Super E3B	2110 2011	3 113 099/100	04102403



Crane Model	Engine		Crane S/No start	Maintenance Manual	1000H Kit P/No
GMK 5130-2	Maraadaa	Chassis E3B	F120.7F01	3 113 091/2	0.41.02.405
GIVIK 5130-2	Mercedes	Super E3B	5130 7501	3 113 091/2	04182405
GMK 5120L	Mercedes	Т3	5120 5601	3 303 262/3	04377843*
GIMIN STZUL	Mercedes	E5	5120 5101	3 303 202/3	04377043^
GMK 5150	Mercedes	T4F	5150 0002	3 302 400/1 or	04181945*
dill (3130	Mercedes	T3	5150 7001	3 303 036/7	01101010
GMK 5150L	Mercedes	T4F	5150 1001	3 302 398/9 or	04181945*
GIVIN 3130E	Mercedes	T3	5150 9001	3 303 034/5	04101343*
GMK 5150-1	Mercedes	E5	5150 3501	3 302 979/80	04326493*
GIVIN 3130 1	Wichecocs		3130 3301	3 302 37 3700	04414023*
CMK E1E0 1	Maraadaa	T4F	E1E0.0E01	2 202 070/00	04326493*
GMK 5150-1	Mercedes	145	5150 0501	3 302 979/80	04414023*
CMK E1E0 1	Marradaa	TO	F1F0.7F01	2 202 070/00	04326493*
GMK 5150-1	Mercedes	Т3	5150 7501	3 302 979/80	04414023*
					04326493*
GMK 5150L-1	Mercedes	E5	5150 4501	3 302 977/8	04414023*
			5.50.50.		04326493*
GMK 5150L-1	Mercedes	T4F	5150 1501	3 302 977/8	04414023*
CNAKE 4 FOL 4	Manada	T2	E450.0504	2 202 077/0	04326493*
GMK 5150L-1	Mercedes	T3	5150 9501	3 302 977/8	04414023*
CMK E1EOVI	Maraadaa		F1F0 0001	2 202 250/60	04326493*
GMK 5150XL	Mercedes	E5	5150 8001	3 303 259/60	04414023*
GMK 5150XL	Mercedes	Т3	5150 6001	3 303 259/60	04326493*
					04414023*
GMK 5170-1	Mercedes	Chassis E3B	5170 4001	3 112 876/7 or	03065745
3 3170	iviercedes	Super E3B	3170 7001	3 113 028/9	00000773
CMK F220	Marradas	Chassis E3B	F220 4004	3 113 026/7 or	02005745
GMK 5220	Mercedes	Super E3B	5220 4001	3 302 372	03065745



<sup>\*</sup> please consider signalcode/infotext

Crane Model	En	gine	Crane S/No start	Maintenance Manual	1000H Kit P/No	
CMV E400 4	Manada	T4F	5180 5001	2 202 025 /0	0.44.054.20.	
GMK 5180-1	Mercedes	E3A	5180 6001	3 302 935/6	04165132*	
	ĺ	E5	5180 8501			
GMK 5180-1	Mercedes	T3	5180 5501	3 303 080	04377860*	
		T4F	5200 5501	3 302 746	04165132*	
GMK 5200-1	Mercedes	E5	5200 8501	3 303 081/2	04377860*	
		T4F	5250 5001			
GMK 5250L	Mercedes	E3A	5250 6001	3 302 744	04165132*	
		E5	5250 7001			
GMK 5250L-1	Mercedes	Т3	5250 8501	3 303 050/1	04377860*	
GMK 5250L-1	Mercedes	T4F	5250 5501	3 302 870/1	04165132*	
		E5	5250 9501		04377860*	
GMK 5250XL-1	Mercedes	T3	5250 4501	3 303 077/8		
GMK 5250XL-1	Mercedes	T4F	5250 8501	3 302 965/6	04165132*	
GMK 6300L	Mercedes	E3B/T4i	6300 4001	3 302 841/2 or	04163128	
GIVIK 0300L	Mercedes	E3A/T3	6300 3001	3 112 924/5		
GMK 6300L	Mercedes	T4F	6300 5001	3 302 443/4 or	04182012	
GIVIN 0300L	Mercedes	T3	6300 3001	3 302 807	04326516	
		E5	6300 6001		04377822	
GMK 6300L-1	Mercedes	T4F	6300 5096	3 302 718/9 or 3 302 873/4	04182012	
		T3	6300 3502		04326516	
CNII/ CADO	Manadas	E3B/T4i	6400 2001	3 113 072/3 or	04400405	
GMK 6400	Mercedes	E3A/T3	6400 3001	3 302 755/6	04182195	
01414.0400.4		E5	6400 4001		0.4000070	
GMK 6400-1	Mercedes	T3	6400 3501	3 303 218	04362376	
CNAV CAEO 1	Manada	E5	6400 4001	3 303 251 or	0.4200270	
GMK 6450-1	Mercedes	T3	6400 3501	4 409 014/15/29/30	04362376	
GMK 7450	Mercedes	E3A/T3	7450 8001	3 112 912/52	04163129	
GMK 7450	Cummins	T4F	7450 9001	3 302 576/7	04299638	

<sup>\*</sup> please consider signalcode/infotext



# MAINTENANCE KITS



# **2000 HOURS**







Contains all parts needed for a 24-month inspection including components that are not required for the 1000h kit inspection. \* Grove CONNECT supports the GMK Maintenance kits with serial number display, notification and acknowledgement.



<sup>\*</sup>The content of the kit may differ between the models.

Crane Model	Engin	e	Crane S/No start	Maintenance Manual	2000H Kit P/No
GMK 3050-2	Cummins	T4F / E5	3050 2501	3 302 853/5	04299742
GIVIK 3030-2	Cullillins	T3	3050 1501	3 302 633/3	04299741
GMK 3050-3	Cummins	T4F/E5	3050 2501	3 303 129/30	04299742
GIVIN 3030-3	Cullillills	Т3	3050 1601	3 303 129/30	04299741
GMK 3060-2	Cummins	T4F/E5	3060 2601	3 303 131/2	04299742
GIVIN 3000 Z	Cullillilli	Т3	3060 1601	3 303 131/2	04299741
GMK 3060L-1	Cummins	T4F/E5	3060 7101	3 303 086/7	04299742
GIVIN 3000L-1	Cullillills	Т3	3060 4601	3 303 080//	04299741
		Т3	4080 5101		04425838
GMK 4080-3	Mercedes	E5	4080 4101	3 303 190/1	04423636
		T4F	4080 4080		04425839
		Т3	4090 5101		04425838
GMK 4090-1	Mercedes	E5	4090 4101	3 303 188/9	04425838
GIVIII 4000 T	Wicheedes	T4F	4090 4080	3 303 100/3	04425839
		Т3	4100 7101	3 303 149/50	0.4.405.000
GMK 4100L-2	Mercedes	E5	4100 4301		04425838
GIVIIC 4100E Z	Wicheedes	T4F	4100 4250		04425839
01417.40701		E5	4070 0001		04425834
GMK 4070L		Т3	4070 1001	4 400 050 /0	
0.000	Mercedes	E5	4080 0001	4 409 058/9	
GMK 4080L		Т3	4080 1001	]	
CMIC E1201	Managalaa	Т3	5120 5601	2 202 202/2	04425746
GMK 5120L	Mercedes	E5	5120 5101	3 303 262/3	04425746*
GMK 5150-1	Mercedes	E5	5150 3501	3 302 979/80	04414511* 04414513*
GMK 5150-1	Mercedes	T4F	5150 0501	3 302 979/80	04414511* 04414513*
GMK 5150-1	Mercedes	ТЗ	5150 7501	3 302 979/80	04414511* 04414513*
GMK 5150L-1	Mercedes	E5	5150 4501	3 302 977/8	04414511* 04414513*
GMK 5150L-1	Mercedes	T4F	5150 1501	3 302 977/8	04414511* 04414513*
GMK 5150L-1	Mercedes	ТЗ	5150 9501	3 302 977/8	04414511* 04414513*
CNALCE 1 FOY	N.4 1	E5	5150 8001	†	04414511*
GMK 5150XL	Mercedes	Т3	5150 6001	3 303 259/60	04414513*


<sup>\*</sup> please consider signalcode/infotext



Crane Model	Engine		Crane S/No start	Maintenance Manual	2000H Kit P/No
		T4F	5180 5001	3 302 935/6	04425831*
GMK 5180-1	Maraadaa	ЕЗА	5180 6001	3 302 935/0	04425051*
GMK 5180-1	Mercedes	E5	5180 8501	3 303 080	04425830*
		Т3	5180 5501	3 303 080	04425830*
CMK E200 4	Maraadaa	T4F	5200 5501	3 302 746	04425831*
GMK 5200-1	Mercedes	E5	5200 8501	3 303 081/2	04425830*
CMK FOFOL	Mercedes	T4F	5250 5001	2 202 744	04425024
GMK 5250L	Mercedes	ЕЗА	5250 5501	3 302 744	04425831*
GMK 5250L-1	Mercedes	T4F	5250 5501	3 302 870/1	04425831*
GMK 5250L-1	Mercedes	E5	5250 7001	3 303 050/1	04425830*
GMK 5250L-1	Mercedes	Т3	5250 6501	3 303 050/1	
GMK 5250XL-1	Mercedes	T4F	5250 8501	3 302 965/6	04425831*
CMK FOFOVL 4	Maraadaa	E5	5250 9501	2 202 077/0	04425830*
GMK 5250XL-1	Mercedes	Т3	5250 4501	3 303 077/8	
CMIX COOOL	Marrada	T4F	6300 5001	3 302 443/4 or	04425935
GMK 6300L	Mercedes	Т3	6300 3001	3 302 807	04425928
		T4F	6300 5096		04425935
GMK 6300L-1	Mercedes	E5	6300 6001	3 302 718/9 or 3 302 873/4	04425836
		Т3	6300 3502	3 302 6/3/4	04425928
GMK 6400-1	Mercedes	E5	6400 4001	2 202 210	04414169
GIVIN 0400-1	wiercedes	Т3	6400 3501	3 303 218	04414109
GMK 6450-1	Mercedes	E5	6400 4001	3 303 251 or	04414160
GIVIN 0450-1	iviercedes	T3	6400 3501	4 409 014/15/29/30	04414169

<sup>\*</sup> please consider signalcode/infotext







# BOOM GREASE PLUS

We are proud to offer this new generation, high-density boom sliding surface lubricant that has exceptional perfomance at all temperatures, is long lasting, weather resistant and with tested reliability.



#### The following sizes are available:

#### **Part Number**

**04299657** (replaces: 02314184)

**04299656** (replaces: 03329071)

**04299654** (replaces: 01373458)

**04299655** (replaces: 02314698)

#### Size

400gr. Cartridge

400gr. Cartridge (for spray gun)

10kg Bucket

25kg Bucket



### A WIDER TEMPERATURE RANGE

Smooth boom operation on a telescopic crane is a fundamental requirement to all lifting duties.

Owing to the construction of modern pinned booms, with relatively thin steel sections and large wear pads, this has never been more important.

Furthermore, to ensure the smooth functioning of the cranes in different weather conditions, such as high heat, rain, snow and ice, or even a high level of dust, a special lubricant is essential.

With our latest lubricant solution, **Boom Grease** *Plus*, we have nearly doubled the density at high temperatures, while maintaining the low–temperatures properties. This further reduces wear and prevents stick–slip in all weather conditions.

Perfectly mixable with our previous boom grease. No cleaning out of systems, or washing off from boom surfaces necessary.

The only boom grease product specified and approved by GMK Engineering Design, and packaged specifically for us.





# OTHER ESSENTIAL LUBRICANTS

#### ■ Adhesive Suspension Oil

Penetrates the tight tolerances of the moving parts inside the suspension cylinder, guaranteeing lubrication of all bearing surfaces.

There are no equivalent or suitable alternative oils or greases for this application.



Part Number

02310863 1I 02312890 10I

Usage: Filling of MEGATRAK Suspension Cylinders

#### ■ Penetrant Grease Spray

Applied to the exposed chrome surfaces it fills the plating microsructure through to the underlying steel, giving effective protection against corrosion that other greases and lubricants do not.



Part Number

01929824 400ml

■ Usage: Protection of Crome Surfaces





## OTHER ESSENTIAL LUBRICANTS

#### ■ Gear Teeth Spray

A high-graphite adhesive grease recommended for lubricating the external teeth of GMK turntable bearin.

**Part Number** 

S-01032-63 400ml

Usage: Turntable Bearing Gear Teeth



#### ■ Bolt Grease 2.0

The next generation of high-graphite universal grease, which performs in a much wider temperature range. This highly recommended allrounder can be utilized for a variety of tasks like:



#### Usage:

- The boom foot pin and lift cylinder pins
- The steering elements of the MEGATRAK suspension strut
- Cardan shafts

The central lubrication system

Part Number 03313195 04163374

400g 1kg



# BOOM GREASE SPRAY SET

Part Number 04414162

#### Consisting of:

Boom Grease *Plus* 04299656 (3pcs.)

Hand Spray Gun 04414346

Spray Nozzle Head 04412196





Additional Equipment (not included in set):

**High Pressure Hose 25m** 03329072
To connect to high pressure outlet on the crane





# **BOOM LUBRICATION KIT**

#### Part Number 04414402

Designed to provide easy access to inaccessible places for tasks like lubrication inside the boom through the pinning holes.

#### Consisting of:

•	Grease Gun	04426008
•	Spray Lance	04414389
•	Boom lubrication pump	04425920
•	25kg Boom Grease Plus	04299655
•	High Pressure Hose 6.5m	04426006



Spray lance with long reach to provide easy access to lubricate inside of boom through the pin holes. Length can be adapted by ordering our **Spray Lance Set**, please see next page.

A powerful pneumatic pump and a spray gun with variable pressure setting ensure a homogenous mixture of grease with air, and an even distribution of grease on the boom surface.

High density, long-life boom grease provides maximum protection from corrosion and wear. Prevents stick-slip.



## **SPRAY LANCE SET**

#### Part Number 04414163

In addition to the **Boom Grease Spray Set** and the **Boom Lubrication Kit** we offer you the **Spray Lance Set** for even greater flexibility and to reach those inaccessible areas.

#### Consisting of:

•	Spray Nozzle Head	04412195
•	Spray Lance 170 mm, curved	04414387
•	Spray Lance 500 mm	04414388
•	Spray Lance 1000 mm	04414389
•	Lance Extension 1000 mm	04414390




Lances come in 3 different lengths and can be combined to a maximum length of almost 2 metres. A curved extension allows easy access through the pinning holes.

The 2-stage unlocking of the safety coupling ensures that the lances don't come apart during the spraying process.

Even at full lance extension of 2 metres a regular spray pattern is achieved.





Correct and regular greasing is essential to proper boom operation, will reduce wear and tear and thereby prolong the life span of your equipment.



### **ROPE CLEANER**

#### Part Number 04426185

#### Consisting of:

Portable Grease Transfer System 04426162

Rope Lubrication System 04426160

System Case with straps & shakels 04426163



Increase the working life of your crane rope considerably by regularly greasing and removing dirt and grime with this ingenious device.



## **USE THE RIGHT GREASE**



Dont use just any grease on your rope and risk degrading the rope or the sheaves through adverse chemical reactions.

This Rope Grease is specially formulated to complement the primary rope grease used by the rope manufacturers.



#### Rope Grease (not included in the kit)

Rope Grease 8kg 04426181
 Rope Grease 25kg 04426180

Additional Equipment (not included in set):

**High Pressure Hose 25m** 03329072 To connect to high pressure outlet on the crane



# **ROPE CLEANER**

#### Additional Equipment (not included in kit):

Rope	Cleaner Set P/No	Insert Set P/No	Insert and Cleaner Set P/No
16 mm	04426164	04426169	04426174
17 mm	04426165	04426170	04426175
19 mm	04426166	04426171	04426161
22 mm	04426167	04426172	04426176
24 mm	04426168	04426173	04426177





Continuous lubrication protects against corrosion, reduces friction and significantly extends the lifetime of the ropes.



# ACCUMULATOR CHARGING KIT

Part Number 02257617

#### Consisting of:

•	Hydac bladder accumulators	03317057
•	Leduc bladder accumulators	03139028
•	Case with insert (without tools)	04163029
•	Filling hose	04163028
•	Filling and testing device	04163027

Control of the nitrogen pressure in the accumulators is essential during installation and part of routine maintenance.




## Additional Equipment (not included in kit):

Pressure gauge	04161641
Adapter for GMK 4100L-1 Tele Cylinder Accumulator	04183789
Adapter for GMK 5250L-1 Tele Cylinder Accumulator	03317055
Adapter for previous generation GMK cranes and TMS9000 Slewing Gear Valve Block Accumulator	90021930



# MORE PRESSURE, MORE COMFORT!





If the pressure in the accumulators is too low, the following problems can occur:

- Loss of suspension comfort in the Megatrak
- Possible damage to the Megatrak cylinders, wishbones and ball joints of the steering rods
- Increased wear on tyres

The right tools can make all the difference and help to make regular maintenance quick and trouble–free.



# **BOOM HEAD CAMERA SYSTEM**

Simpler and more precise work through better load control with customized camera system by BCS Cranecamera

The BCS camera system consists of the following main components, among others:

- High-res wide screen monitor type LC
- Camera with zoom and tilt function
- Joystick for zoom and tilt control
- Transmitter (boom head)
- Receiver (base of boom)
- Handheld for zoom and tilt control
- Safety cord

The customized model-specific contents of the kits include the following components in addition to the BCS camera system:

- **Plates**
- Holder
- Adapter cabel short
- Adapter cabel long
- Camera case
- Screws, nuts and washers for installation

















### SAFE AND ROBUST INSTALLATION

All kits contain all the necessary components to ensure safe installation on the crane.

The kits have been put together model–specific due to the different boom heads.

Part Number 04433847

ALSO BEING USED BY POTAIN®

This kit is for the following crane models:

- GMK 3060L-1, GMK 3050-3, GMK 3060-2
- GMK 4090-1, GMK 4080-3
- GMK 4100L-1, GMK 4100L-2, GMK 5120L
- GMK 5150L-1, GMK 5150XL
- Part Number 04433848

This kit is for the following crane model:

- GMK 5250XL
- Part Number 04433849

This kit is for the following crane model:

GMK 6300L-1





A vertical alignment, through a special Auto-Tilt module, ensures a clear view of the hook block.

The camera's tilt angle can be manually adjusted from the superstructure cab using a joystick.

All system functions can be controlled via a multifunctional remote control.



# OTHER USEFUL KITS & TOOLS


Implementing a maintenance strategy can go a long way towards improving reliability by taking the preventive and proactive, instead of the reactive, approach.

Our competitively priced repair solutions, tools and assist devices, for different applications within your maintenance regime, are here to make this as easy and convenient as possible.

You can find more information in the bulletins we have created on each topic.

MEGATRAK Installation Aid 04257034

Battery Charger (220 V) 04326178





Wishbone Repair Kit 04163676



Ad Blue Analysis Set 04433854



# OTHER USEFUL KITS & TOOLS

Subject	Bulletin	Part Number	Description
Wishbone Repair	SB D15-007	04163676	Wishbone Repair Kit
Suspension	PB D19-308	04257034	Mounting Tool MegaTRAK Strut
Mounting Tools		04257055	Mounting Tool Wheel Drive
GMK Sheave Inspection	PB D20-307	04286259	Measuring Tool for Sheave Groove
Oil Analysis		03141012	Oil Analysis Kit
Ad Blue Analysis		04433854	Ad Blue Analysis Set
GMK3050-1 Boom Retraction Cable Inspection	PB D20-309	04182194	Boom Retracttion Cable Kit
Battery Maintenance	PD D20-310	04326178 220V 04326279 110V	Battery Charger with Adaptor Plug
GMK Cardan Shafts	PB D20-308		Recommended Cardan Shaft Care
CCS Jog Dial	PB D20-305	03312583	Repair Kit
Accumulator Charging	PB D24-303	02257617	Accumulator Charging Kit
Hydraulic Leaks	PB D22-301	03312789 450ml 03312791 150ml	Leak Detection Agent
GMK Hoist Maintenance	PB D22-308	see bulletin	Hoist brake & gear exchange program



### TRAINING

Our Training Centers offer courses for operators and technicians across the globe to provide in–depth instruction on crane operation, maintenance, and troubleshooting procedures.

Experienced trainers provide instruction to thousands of crane technicians and operators each year in our training centers worldwide.

Facilities include interactive training tools, fully furnished classrooms, crane operation simulators, test cranes, and lab workstations with equipment appropriate for the specific cranes and curriculum levels.

Instructor-led courses at one of our training centers are typically 3–5 days long.

- Training availabe in several languages
- Strategic locations around the world





## HIGH QUALITY TRAINING, ADAPTED TO YOUR NEEDS.

We can accommodate many language needs. Our training team speaks English, German, Spanish, Portuguese, Dutch, Italian, French, and Mandarin.

Short, online, e-Learning modules are also available to provide supplemental training material. To review our course offerings, please see our regional training catalogs at https://www.manitowoc.com/support/training.

If you have any questions about our training program or would like a quote, please contact us using the information in your regional training catalog or at one of the email addresses below.

- **Europe:** trainingGMK@manitowoc.com
- Latin America: LATAM.training@manitowoc.com
- Rest of the World: factorytraining@manitowoc.com



## DIAGNOSTIC TOOLS







Expert tools for diagnostics and programming

Scan the QR code to see the complete listing of tools and available training classes on our website:





## **DIAGNOSTIC TOOLS**

Over the years, there have been different versions of crane operating systems, rated capacity limiters and engine/transmission combinations on GMK cranes. These all requiere some variation of cables and tools to perform the neccessary interaction.

To help you identify all these old and new GMK diagnostic cables and tools that are required for trouble-shooting and programming of GMK cranes we have compiled an overview for your easy reference available for download from our website.

Please note that some of these tools are only available after taking the prerequisite training.

For a complete listing of all available diagnostic tools please reference bulletin D19-007.





## KEEP YOUR CRANE CONNECTED

Grove CONNECT changes the user experience and makes the daily work of crane operators easier.

With Grove CONNECT, crane utilization can be increased while reducing operating costs and environmental impact.

In addition to a wide range of functions, Grove CONNECT enables easy access to the entire crane fleet in real time.











#### ACCESS:

Easy remote access to your complete fleet in real time. Guided troubleshooting assistant. RCL, active faults / faults history, crane configuration.

#### **ANALYTICS** function:

Several reports based on stored cloud data for crane utilization, crane perfomance and predictive service / maintenance.

#### ADMIN function:

Self-Service for Customer / Service Partners, Crane Access, Crane Delegation(s), Crane Transfer(s)
Manage user access: internal and external user accounts

#### APT:

Connect fleet data to your information system. Interface for 3rd party system fleet management systems AEMP 1.2





Scan the QR code to check the Grove CONNECT availability in your Country:



### RETROFIT KIT

Part Number 04414411



## Grove CONNECT™ is available for:

• GMK3050-2

| GMK3050-3

GMK3060-1

| GMK3060-2

• GMK3060L

| GMK3060L-1

GMK4070L

GMK4080L

GMK4080-2 | GMK4080-3

• GMK4090

I GMK4090-1

• GMK4100L-1

I GMK4100L-2

• GMK5120L

• GMK5150

I GMK5150-1

GMK5150L

| GMK5150L-1

GMK5150XL

GMK5180-1 | GMK5200-1

GMK5250L

I GMK5250L-1

GMK5250XL-1

• GMK6400-1

| GMK6450-1



## MANITOWOC APP CENTER

The Manitowoc App Center features a centralized overview for the Diagnostic Code App, Manitowoc Garage "How-to" videos, an updated Dealer Locator search interface and the new Permissible Wind Speed Calculator app.

Download Manitowoc's FREE smartphone APP for iOS and Android devices to help interpret diagnostic codes generated by a crane's operating system.

## Scan the matching QR code below to download the App for your device :



i0S



Android



## MANITOWOC APP CENTER

Application supports diagnostic codes on all our cranes running Manitowoc's Crane Control System (CCS) and GMK models running the ECOS1 or ECOS2 systems.

Quick assistance in troubleshooting.







## REBUILD PREMIUM ENCORE

Through the **EnCORE** program you can have your crane rebuilt and brought back to original OEM specifications.

- Give your crane a 2nd life bringing it back to like new condition.
- Premium EnCORE Rebuild comes with a full one year warranty for parts & labor.
- Crane will have a new S/N with an "R" designation
- Retain legacy operator knowledge.
- Higher resale value
- LMI and software brought up to the most current version available for your particular model.
- All work completed by EnCORE Certified Facilities.





## Rebuild. Repair. Remanufacture. Exchange.

## Overhaul EnCORE package:

If you are looking to upgrade your machine, the EnCORE team can work with you on a overhaul package.

Whether it is electrical, hydraulic or any of the other major systems that are in need of a rebuild.

We will create an overhaul kit package to meet your needs at very competive pricing compared to purchasing parts individually.

- Original OEM components
- Competively priced
- EnCORE can supply labor if needed to install your new overhaul package
- Upgrades your system to like new condition.
- 1 year parts warranty



## REMANUFACTURE

EnCORE is establishing a Global Remanufacturing program which will allow EnCORE to offer our customers a part that has been remanufactured back to original OEM specifications.

Components include hydraulic cylinders, pumps and motors, electrical components and other vital components of your crane.

Hoist Brake

01d







### Advantages:

- Fast availability
- Competively priced compared to new
- Attractive core return credit for usable old part
- 1 Year Parts Warranty

#### Large Cylinder Remanufacturing



Disassembly



Inspection




Remanufactured Cylinder



## COME CLEAN!

As part of your Reman program we offer a professional cleaning service for your **Diesel Particulate Filter (DPF)**.



- The ordering process is the same as for any other R-Part.
   Attractive core return credit for viable core.
- Parts warranty is the same as for a new part (1 year).
- Each cleaned filter will receive a certificate after cleaning by our partner that lists the weight of the ash deposits removed and the serial number of the filter which is needed for recalibration.



## REPAIR

If your crane has been in an accident or damaged the EnCORE team can repair your crane back to original OEM specifications.

- Damaged component is repaired back to original OEM specification
- Peace of mind and the assurance that the correct material is being used to ensure a safe and reliable component being put back into service.
- Component will be thoroughly inspected to ensure all damage has been identified and repaired properly.







## NOTES



## NOTES



## NOTES



# The Manitowoc Company, Inc.

### Regional headquarters

#### **Americas**

Milwaukee, Wisconsin, USA

Tel: + 1 414 760 4600

Shady Grove, Pennsylvannia, USA

Tel: + 1 717 597 8121

#### **APAC**

Shanghai, China

Tel: +86 21 6457 0066

**Singapore** 

Tel: +65 6264 1188

**Europe and Africa** 

Dardilly, France - TOWERS

Tel: +33 (0) 4 72 18 20 20

Wilhelmshaven, Germany - MOBILE

Tel: +49 (0) 4421 294 0

Middle East and India

Dubai, UAE

Tel: +971 4 8862677

This document is non-contractual.

Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment, and the price changes without notice. Illustrations shown may include optional equipment and accessories and

©2025 The Manitowoc Company, Inc. Care Catalogue CC 04/2025

may not include all standard equipment.

#### FIND YOUR LOCAL DEALER AT:



https://www.manitowoc.com/dealer-locator